



## COMPONENTS




Length:  
2,7 m



Length: 1,5 m, 2,0 m, 2,5 m,  
3,0 m, 4,0 m, 6,0 m




Length: 1,5 m, 2,0 m, 2,5 m,  
3,0 m, 4,0 m, 6,0 m






Length: 1,5 m, 2,0 m, 2,5 m,  
3,0 m, 4,0 m, 6,0 m




Length:  
50,0 m



Length:  
1,7 m, 2,35 m, 3,0 m



Dimensions of opening




handle length = door height

**door filling** – #18 mm board, #16 mm, #12 mm + mirror

door height - without soft-close	- h	$h = H - 40 \text{ mm}$
- with soft-close Simple MINI and Simple CENTRAL		$h = H - 45 \text{ mm}$
board height	- hb	$hb = h - 1 \text{ mm}$
door width	- w	$w = (W - 3 + Z) : N$
board width #18	- wb	$wb = w - 37 \text{ mm}$
board width #12/#16	- wb	$wb = w - 17 \text{ mm}$
angle section length	- la	$la = w - 57 \text{ mm}$

number of doors	- N	2	3
total overlap	- Z	30 mm	60 mm

visual design – 4 wings	
	$w = (W + 87) : 4$
	$w = (W : 2 + 27) : 2$




**mirror dimensions**

mirror height -  $hm = hb - 4 \text{ mm}$   
 mirror width -  $w_m = wb_m - 6 \text{ mm}$


Broken line indicates recommended positioning of double-sided tape

- When fitting handle profiles, do not use assembly adhesive



**Installation method for handle and guiding carriage with #18 mm board**



**Installation method for handle and guiding carriage with #16 mm board or #12 mm board + #4 mm mirror**



**Installation method for angle section 11 mm x 17 mm**



**WARNING**

*We do not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity).*

**ATTENTION:**

Board to mirror contact area should be free from dirt and grease before applying double-sided tape.