


COMPONENTS

<p>Handle Libra</p> <p>#4 / #18</p> <p>textile door stop, inserted 14 mm x 4 mm</p> <p>anti-dust brush inserted 6.7 mm x 13 mm</p> <p>Length: 2.7 m</p>	<p>Top track Blue</p> <p>75 mm</p> <p>Length: 1.5 m, 2.0 m, 2.5 m, 3.0 m, 4.0 m, 6.0 m</p>	<p>Rubber finishing profile for bottom track</p> <p>Length: 50.0 m</p>	<p>Bottom track Blue-V</p> <p>Option 1</p> <p>48 mm</p> <p>Length: 1.5 m, 2.0 m, 2.5 m, 3.0 m, 4.0 m, 6.0 m</p>	<p>Bottom track Blue-C</p> <p>Option 2</p> <p>42 mm</p> <p>Length: 1.5 m, 2.0 m, 2.5 m, 3.0 m, 4.0 m, 6.0 m</p>	<p>H28 Simple mid-rail</p> <p>Length: 3.0 m</p>	<p>H21 Simple mid-rail</p> <p>Length: 3.0 m</p>
<p>Top horizontal profile Simple Frame II</p> <p>Length: 1.5 m, 2.0 m, 2.5 m, 3.0 m</p>	<p>Bottom horizontal profile Simple Frame II</p> <p>Length: 1.5 m, 2.0 m, 2.5 m, 3.0 m</p>	<p>Guiding carriage Blue 18 Frame</p> <p>(Set)</p>	<p>Bottom carriage Simple/Blue 10V</p> <p>Opcja 1</p> <p>(Set)</p>	<p>Bottom carriage Blue 10C</p> <p>Option 2</p> <p>(Set)</p>	<p>Self-tapping screw $\varnothing 6.3 \times 32$</p>	<p>Fastening wedge for glass Blue Frame/ Simple Frame</p> <p>Blue Frame</p> <p>Simple Frame</p>

Dimensions of opening




door filling – #18 mm board, #4 mm glass

door height	- h	$h = H - 35 \text{ mm}$
- without soft-close		
- with soft-close Simple MINI & Simple Central (bottom carriage Blue 10V)		$h = H - 39 \text{ mm}$
- with soft-close Simple MINI & Simple Central (bottom carriage Blue 10C)		$h = H - 42 \text{ mm}$
board height	- hb	$hb = h - 60 \text{ mm}$
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$
board width	- wb	$wb = w - 17 \text{ mm}$
horizontal profile length	- L	$L = U = w - 40.4 \text{ mm}$
upper horizontal profile length	- U	

number of doors	- N	2	3
total overlap	- Z	32 mm	64 mm


visual design – 4 wings	
	$w = (W + 93) : 4$
	$w = (W : 2 + 29) : 2$



door filling – 4 mm glass or mirror


mirror height	- hm	$hm = hb$
mirror width	- wm	$wm = wb - 4 \text{ mm}$

Dimensions helpful during installation of horizontal mid-rails in Blue-Frame systems




Installation method for fitting 18 mm board (diag. A) and 4 mm mirror or glass (diag. B)

- with handle




- with top horizontal profile



Expansion gap taken into account when calculating the height of chipboard

- with bottom horizontal profile



Two types of wedges can be used in the horizontal profiles: Fastening wedge **Blue** (protrudes over the profile edge) or Fastening wedge **Simple** (sits level with the profile edge)

ATTENTION!

Mirror (4mm) should be used with a safety backing film. Safety glass (4.5mm) comprises of two thin layers with a film in-between.